

Changing the oil in your car

Once every 6000 kilometers or three months, change the oil in your car. This will help keep the engine in good condition.

To change the oil:

1. Remove the old oil filter.
2. Drain the old oil.
3. Install a new oil filter and gasket.
4. Add new oil to the engine.
5. Check the air filter and replace or clean it.
6. Top up the windshield washer fluid.